

License to Enable Redundancy Functionality for ANANT UCS

- No. of Users: 500
- License will be Activated on the Primary Server Hardware
- All Feature Licenses will be Duplicated on the Secondary Hardware when the Primary Hardware
- Fails

Note: Additional (Redundant) server hardware is required for redundancy function to work. No License is required to be activated on the redundant hardware for redundancy functionality.